

# Agilent 33220A

## Function/Arbitrary Waveform Generator

### Quick Reference Guide

- Square brackets ( [ ] ) indicate optional keywords or parameters.
- Braces ( { } ) enclose parameters within a command. Default parameters are shown in **bold**.
- Triangle brackets ( < > ) enclose parameters for which you must substitute a value.
- A vertical bar ( | ) separates multiple choices.

### The APPLy Commands

(see page 163 in User's Guide)

#### APPLy

```
:SINusoid [<frequency> [, <amplitude> [, <offset>] ]]  
:SQUare [<frequency> [, <amplitude> [, <offset>] ]]  
:RAMP [<frequency> [, <amplitude> [, <offset>] ]]  
:PULSe [<frequency> [, <amplitude> [, <offset>] ]]  
:NOISe [<frequency>|DEF1 [, <amplitude> [, <offset>] ]]  
:DC [<frequency>|DEF1 [, <amplitude>|DEF1 [, <offset>] ]]  
:USER [<frequency> [, <amplitude> [, <offset>] ]]
```

#### APPLy?

<sup>1</sup> This parameter has no effect for this command but you **MUST** specify a value or "DEFault".

### State Storage Commands

(see page 238 in User's Guide)

```
*SAV {0|1|2|3|4}  
*RCL {0|1|2|3|4}
```

#### MEMory:STATe

```
:NAME {0|1|2|3|4} [, <name>]  
:NAME? {0|1|2|3|4}  
:DELeTe {0|1|2|3|4}  
:RECall:AUTO {OFF|ON}  
:RECall:AUTO?  
:VALId? {0|1|2|3|4}
```

#### MEMory:NStates?



## Output Configuration Commands

(see page 172 in User's Guide)

```
FUNCTION {SINu|SQU|RAMP|PULSe|NOISE|DC|USER}
FUNCTION?

FREQUENCY {<frequency>|MINimum|MAXimum}
FREQUENCY? [MINimum|MAXimum]

VOLTage {<amplitude>|MINimum|MAXimum}
VOLTage? [MINimum|MAXimum]

VOLTage:OFFSet {<offset>|MINimum|MAXimum}
VOLTage:OFFSet? [MINimum|MAXimum]

VOLTage
  :HIGH {<voltage>|MINimum|MAXimum}
  :HIGH? [MINimum|MAXimum]
  :LOW {<voltage>|MINimum|MAXimum}
  :LOW? [MINimum|MAXimum]

VOLTage:RANGE:AUTO {OFF|ON|ONCE}
VOLTage:RANGE:AUTO?

VOLTage:UNIT {VPP|VRMS|DBM}
VOLTage:UNIT?

FUNCTION:SQUare:DCYCLE {<percent>|MINimum|MAXimum}
FUNCTION:SQUare:DCYCLE? [MINimum|MAXimum]

FUNCTION:RAMP:SYMMetry {<percent>|MINimum|MAXimum}
FUNCTION:RAMP:SYMMetry? [MINimum|MAXimum]

OUTPut {OFF|ON}
OUTPut?

OUTPut:LOAD {<ohms>|INFINITY|MINimum|MAXimum}
OUTPut:LOAD? [MINimum|MAXimum]

OUTPut:POLarity {NORMAL|INVERTed}
OUTPut:POLarity?

OUTPut:SYNC {OFF|ON}
OUTPut:SYNC?
```

## Pulse Configuration Commands

(see page 185 in User's Guide)

```
PULSe:PERiod {<seconds>|MINimum|MAXimum}
PULSe:PERiod? [MINimum|MAXimum]

FUNCTION:PULSe
  :HOLD {WIDTH|DCYCLE}
  :HOLD? [WIDTH|DCYCLE]
  :WIDTH {<seconds>|MINimum|MAXimum}
  :WIDTH? [MINimum|MAXimum]
  :DCYCLE {<percent>|MINimum|MAXimum}
  :DCYCLE? [MINimum|MAXimum]
  :TRANSition {<seconds>|MINimum|MAXimum}
  :TRANSition? [MINimum|MAXimum]
```

## Modulation Commands

(see page 190 in User's Guide)

### AM Commands

```
AM:INTernal
:FUNCTION {SIN|SQU|RAMP|NRAMP|TRI|NOISE|USER}
:FUNCTION?
```

```
AM:INTernal
:FREQUENCY {<frequency>|MINimum|MAXimum}
:FREQUENCY? [MINimum|MAXimum]
```

```
AM:DEPTH {<depth in percent>|MINimum|MAXimum}
AM:DEPTH? [MINimum|MAXimum]
```

```
AM:SOURCE {INTernal|EXTernal}
AM:SOURCE?
```

```
AM:STATE {OFF|ON}
AM:STATE?
```

### FM Commands

```
FM:INTernal
:FUNCTION {SIN|SQU|RAMP|NRAMP|TRI|NOISE|USER}
:FUNCTION?
```

```
FM:INTernal
:FREQUENCY {<frequency>|MINimum|MAXimum}
:FREQUENCY? [MINimum|MAXimum]
```

```
FM:DEVIATION {<peak deviation in Hz>|MINimum|MAXimum}
FM:DEVIATION? [MINimum|MAXimum]
```

```
FM:SOURCE {INTernal|EXTernal}
FM:SOURCE?
```

```
FM:STATE {OFF|ON}
FM:STATE?
```

### PM Commands

```
PM:INTernal
:FUNCTION {SIN|SQU|RAMP|NRAMP|TRI|NOISE|USER}
:FUNCTION?
```

```
PM:INTernal
:FREQUENCY {<frequency>|MINimum|MAXimum}
:FREQUENCY? [MINimum|MAXimum]
```

```
PM:DEVIATION {<deviation in degrees>|MINimum|MAXimum}
PM:DEVIATION? [MINimum|MAXimum]
```

```
PM:SOURCE {INTernal|EXTernal}
PM:SOURCE?
```

```
PM:STATE {OFF|ON}
PM:STATE?
```

## FSK Commands

```
FSKey:FREQuency {<frequency>|MINimum|MAXimum}
FSKey:FREQuency? [MINimum|MAXimum]

FSKey:INTernal:RATE {<rate in Hz>|MINimum|MAXimum}
FSKey:INTernal:RATE? [MINimum|MAXimum]

FSKey:SOURce {INTERNAL|EXTERNAL}
FSKey:SOURce?

FSKey:STATe {OFF|ON}
FSKey:STATe?
```

## PWM Commands

```
PWM:INTernal
:FUNCTion {SIN|SQU|RAMP|NRAMP|TRI|NOISE|USER}
:FUNCTion?

PWM:INTernal
:FREQuency {<frequency>|MINimum|MAXimum}
:FREQuency? [MINimum|MAXimum]

PWM:DEVIation {<deviation in seconds>|MIN|MAX}
PWM:DEVIation? [MINimum|MAXimum]

PWM:DEVIation:DCYCLE {<deviation in percent>|MIN|MAX}
PWM:DEVIation:DCYCLE? [MINimum|MAXimum]

PWM:SOURce {INTERNAL|EXTERNAL}
PWM:SOURce?

PWM:STATe {OFF|ON}
PWM:STATe?
```

## Burst Commands

(see page 216 in User's Guide)

```
BURSt:MODE {TRIGgered|GATED}
BURSt:MODE?

BURSt:NCYCLes {<#cycles>|INFinity|MINimum|MAXimum}
BURSt:NCYCLes? [MINimum|MAXimum]

BURSt:INTernal:PERiod {<seconds>|MINimum|MAXimum}
BURSt:INTernal:PERiod? [MINimum|MAXimum]

BURSt:PHASe {<angle>|MINimum|MAXimum}
BURSt:PHASe? [MINimum|MAXimum]

BURSt:STATe {OFF|ON}
BURSt:STATe?

UNIT:ANGLe {DEGREE|RADian}
UNIT:ANGLe?

TRIGger:SOURce {IMMediate|EXternal|BUS}
TRIGger:SOURce?

TRIGger:SLOPe {POSitive|NEGative}
TRIGger:SLOPe?

BURSt:GATE:POLarity {NORMal|INVerted}
BURSt:GATE:POLarity?

OUTPut
:TRIGger:SLOPe {POSitive|NEGative}
:TRIGger:SLOPe?
:TRIGger {OFF|ON}
:TRIGger?
```

## Sweep Commands

(see page 208 in User's Guide)

### FREQuency

```
:START {<frequency>|MINimum|MAXimum}
:START? [MINimum|MAXimum]
:STOP {<frequency>|MINimum|MAXimum}
:STOP? [MINimum|MAXimum]
```

### FREQuency

```
:CENTER {<frequency>|MINimum|MAXimum}
:CENTER? [MINimum|MAXimum]
:SPAN {<frequency>|MINimum|MAXimum}
:SPAN? [MINimum|MAXimum]
```

### SWEep

```
:SPACing {LINear|LOGarithmic}
:SPACing?
:TIME {<seconds>|MINimum|MAXimum}
:TIME? [MINimum|MAXimum]
```

```
SWEep:STATE {OFF|ON}
```

```
SWEep:STATE?
```

```
TRIGger:SOURce {IMMediate|EXTernal|BUS}
```

```
TRIGger:SOURce?
```

```
TRIGger:SLOPe {POSitive|NEGative}
```

```
TRIGger:SLOPe?
```

### OUTPut

```
:TRIGger:SLOPe {POSitive|NEGative}
:TRIGger:SLOPe?
:TRIGger {OFF|ON}
:TRIGger?
```

```
MARKer:FREQuency {<frequency>|MINimum|MAXimum}
```

```
MARKer:FREQuency? [MINimum|MAXimum]
```

```
MARKer {OFF|ON}
```

```
MARKer?
```

## Triggering Commands

(see page 224 in User's Guide)

*These commands are used for Sweep and Burst only.*

```
TRIGger:SOURce {IMMediate|EXTernal|BUS}
```

```
TRIGger:SOURce?
```

```
TRIGger
```

```
*TRG
```

```
TRIGger:SLOPe {POSitive|NEGative}
```

```
TRIGger:SLOPe?
```

```
BURSt:GATE:POLarity {NORMAL|INVerted}
```

```
BURSt:GATE:POLarity?
```

### OUTPut

```
:TRIGger:SLOPe {POSitive|NEGative}
:TRIGger:SLOPe?
:TRIGger {OFF|ON}
:TRIGger?
```

## System-Related Commands

(see page 242 in User's Guide)

SYSTem:ERRor?

\*IDN?

DISPlay {OFF|ON}  
DISPlay?

DISPlay  
:TEXT <quoted string>  
:TEXT?  
:TEXT:CLEar

\*RST

\*TST?

SYSTem:VERSion?

SYSTem  
:BEEPer  
:BEEPer:STATe {OFF|ON}  
:BEEPer:STATe?

SYSTem  
:KLOCK[:STATe] {OFF|ON}  
:KLOCK:EXCLude {NONE|LOCAL}

SYSTem:SECurity:IMMediate **Caution.** Clears all memory. Not recommended for routine applications.

\*LRN?

\*OPC

\*OPC?

\*WAI

## Interface Configuration Commands

(see page 247 in User's Guide)

SYSTem:COMMunicate:RLState {LOCAL|REMOTE|RWLock}

---

© Copyright Agilent Technologies, Inc. 2003  
Printed in Malaysia February 2003 E0203



33220-90007

## Arbitrary Waveform Commands

(see page 227 in User's Guide)

```
DATA VOLATILE, <value>, <value>, ...
DATA
  :DAC VOLATILE, {<binary block>|<value>, <value>, ... }
FORMat:BORDER {NORMal|SWAPped}
FORMat:BORDER?
DATA:COPY <destination arb name> [,VOLATILE]
FUNCTION:USER {<arb name>1|VOLATILE}
FUNCTION:USER?
FUNCTION USER
FUNCTION?
DATA
  :CATalog?
  :NVOLatile:CATalog?
  :NVOLatile:FREE?
DATA:DELeTe <arb name>
DATA:DELeTe:ALL
DATA
  :ATTRibute:AVERage? [<arb name>1]
  :ATTRibute:CFACTOR? [<arb name>1]
  :ATTRibute:POINTs? [<arb name>1]
  :ATTRibute:PTPeak? [<arb name>1]
```

<sup>1</sup> The names of the built-in arb waveforms are:  
EXP\_RISE, EXP\_FALL, NEG\_RAMP, SINC, and CARDIAC.

## Status Reporting Commands

(see page 260 in User's Guide)

```
*STB?
*SRE <enable value>
*SRE?
STATus
  :QUESTionable:CONDition?
  :QUESTionable[:EVENT]?
  :QUESTionable:ENABle <enable value>
  :QUESTionable:ENABle?
*ESR?
*ESE <enable value>
*ESE?
*CLS
STATus:PRESet
*PSC {0|1}
*PSC?
*OPC
```

(See page 251 in the User's Guide for a diagram of the SCPI status system.)

## Phase-Lock Commands

These commands require Option 001, External Timebase Reference (see page 248 in User's Guide).

```
PHASe {<angle>|MINimum|MAXimum}
PHASe? [MINimum|MAXimum]
PHASe:REFerence
PHASe:UNLock:ERRor:STATe {OFF|ON}
PHASe:UNLock:ERRor:STATe?
UNIT:ANGLE {DEGREE|RADIAn}
UNIT:ANGLE?
```

## Calibration Commands

(see page 264 in User's Guide)

```
CALibration?
CALibration
:SECure:STATe {OFF|ON}, <code>
:SECure:STATe?
:SECure:CODE <new code>
:SETup <0|1|2|3| . . . |94>
:SETup?
:VALue <value>
:VALue?
:COUNT?
:STRing <quoted string>
:STRing?
```

## IEEE 488.2 Common Commands

```
*CLS
*ESR?
*ESE <enable value>
*ESE?
*IDN?
*LRN?
*OPC
*OPC?
*PSC {0|1}
*PSC?
*RST
*SAV {0|1|2|3|4}
*RCL {0|1|2|3|4}
*STB?
*SRE <enable value>
*SRE?
*TRG
*TST?
```



## Simplified Programming Overview

### Using the APPLy Command

The APPLy command provides the most straightforward method to program the function generator over the remote interface. For example, the following command string sent from your computer will output a 3 V<sub>pp</sub> sine wave at 5 kHz with a -2.5 volt offset.

```
APPL:SIN 5.0E+3, 3.0, -2.5
```

### Using the Low-Level Commands

Although the APPLy command provides the most straightforward method to program the function generator, the low-level commands give you more flexibility to change individual parameters. For example, the following command strings sent from your computer will output a 3 V<sub>pp</sub> sine wave at 5 kHz with a -2.5 volt offset.


```
FUNC SIN  
FREQ 5000  
VOLT 3.0  
VOLT:OFFS -2.5
```

### Reading a Query Response

Only the query commands (commands that end with “?”) will instruct the function generator to send a response message. Queries return internal instrument settings. For example, the following command string sent from your computer will read the function generator’s error queue and retrieve the response from the most recent error.

```
SYST:ERR?  
enter statement
```

### Selecting a Trigger Source

When *Sweep* or *Burst* is enabled, the function generator will accept an immediate internal trigger, a hardware trigger from the rear-panel *Trig In* connector, a manual trigger from the  key, or a software (bus) trigger. By default, the internal trigger source is selected. If you want to use an external or a software trigger source, you must first select that source. For example, the following command strings sent from your computer will output a 3-cycle burst each time the rear-panel *Trig In* connector receives the rising edge of a TTL pulse.

```
BURS:NCYC 3  
TRIG:SLOP POS  
TRIG:SOUR EXT  
BURS:STAT ON
```

## Factory Default Settings

|                                  |                        |
|----------------------------------|------------------------|
| <b>Output Configuration</b>      | <b>Factory Setting</b> |
| Function                         | Sine wave              |
| Frequency                        | 1 kHz                  |
| Amplitude / Offset               | 100 mVpp / 0.0 Vdc     |
| Output Units                     | Vpp                    |
| Output Termination               | 50 $\Omega$            |
| Autorange                        | On                     |
| <b>Modulation</b>                | <b>Factory Setting</b> |
| Carrier (AM, FM, PM, FSK)        | 1 kHz Sine wave        |
| Carrier (PWM)                    | 1 kHz Pulse            |
| Modulating Waveform:             |                        |
| (AM)                             | 100 Hz Sine wave       |
| (FM, PM, PWM)                    | 10 Hz Sine wave        |
| AM Depth                         | 100%                   |
| FM Deviation                     | 100 Hz                 |
| PM Deviation                     | 180 degrees            |
| FSK Hop Frequency                | 100 Hz                 |
| FSK Rate                         | 10 Hz                  |
| PWM Width Deviation              | 10 $\mu$ s             |
| Modulation State                 | Off                    |
| <b>Sweep</b>                     | <b>Factory Setting</b> |
| Start / Stop Frequency           | 100 Hz / 1 kHz         |
| Sweep Time                       | 1 Second               |
| Sweep Mode                       | Linear                 |
| Sweep State                      | Off                    |
| <b>Burst</b>                     | <b>Factory Setting</b> |
| Burst Count                      | 1 Cycle                |
| Burst Period                     | 10 ms                  |
| Burst Start Phase                | 0 degrees              |
| Burst State                      | Off                    |
| <b>System-Related Operations</b> | <b>Factory Setting</b> |
| • Power-Down Recall              | • Disabled             |
| Display Mode                     | On                     |
| Error Queue                      | Errors are Cleared     |
| Stored States, Stored Arbs       | No Change              |
| Output State                     | Off                    |
| <b>Triggering Operations</b>     | <b>Factory Setting</b> |
| Trigger Source                   | Internal (Immediate)   |
| <b>Remote Interface Config.</b>  | <b>Factory Setting</b> |
| • GPIB Address                   | • 10                   |
| • DHCP                           | • On                   |
| • IP Address                     | • 169.254.002.020      |
| • Subnet Mask                    | • 255.255.000.000      |
| • Default Gateway                | • 000.000.000.000      |
| • DNS Server                     | • 000.000.000.000      |
| • Host Name                      | • none                 |
| • Domain Name                    | • none                 |
| <b>Calibration</b>               | <b>Factory Setting</b> |
| Calibration State                | Secured                |

Parameters marked with a bullet (•) are stored in *non-volatile* memory.